easiMARK Transfer Remover

product specification

For removing most garment transfers.





step by step guide

shake	spray	wait	remove
shake aerosol can before use	spray directly onto the emblem from both directions	wait at least 1 minute but no longer than 2 minutes	remove the badge from the item of clothing

PREPARATION CONTAINING

DICHLOROMETHANE, METHANOL

Harmful by inhalation, in contact with skin and if swallowed. Limited evidence of a carcinogenic effect. Harmful: possible risk of irreversible effects through inhalation, in contact with skin and if swallowed. Keep away from sources of ignition – NO Smoking. Keep out of reach of children. Do not breathe gas/fumes/vapour/spray. Avoid contact with skin and eyes. Wear suitable protective clothing and gloves. Use only in well ventilated areas.

CAUTION

Pressurised container

Protect from sunlight and do not expose to temperatures exceeding 50°C.

Do not pierce or burn even after use.

Do not spray on a naked flame or any incandescent material.

Un 1950





Telephone: **01246 570570**Fax: **08000 157005**